




# F Brake Light Wiring Diagram And F Gauge Cluster Wiring Diagram By XPMissions

# F brake light wiring diagram and f gauge cluster wiring diagram



Click to enlarge

## 1995 Instrument Cluster



TERMINAL	WIRING	FUNCTION
12	210 (LB)	544 Indicator Input
13	640 (R/Y)	Power Supply in RUN and START
14	16 (R/LG)	Charge Indicator Input

C251 (GRAY) INSTRUMENT CLUSTER		
PIN NUMBER	CIRCUIT	CIRCUIT FUNCTION
1	875 (BK/LB)	Unique Ground to Gauges
2	608 (PK/LG)	"Check Engine Indicator" Input
3	603 (DG)	Anti-lock Brake Warning Indicator Input
4	977 (P/W)	Brake Warning Indicator Input
5	343 (DB/LG)	Anti-Theft Indicator Input
6	28 (Y/W)	Fuel Level Input (without tachometer)
7	3 (L/G/W)	Left Turn Input
8	31 (W/R)	Oil Pressure Input
9	875 (BK/LB)	Unique Ground to Gauges
10	39 (R/W)	Temperature Input
11	-	NOT USED
12	608 (BK/Y)	Air Bag Indicator
13	840 (R/Y)	Power to Gauges, Hot in START or RUN
14	-	NOT USED

xpmissions.com