


Jeep Wrangler Blower Motor Wiring Diagram And Jeep Liberty Wiring Diagram By XPMissions

Jeep wrangler blower motor wiring diagram and jeep liberty wiring diagram

8W - 12 - 2 8W-12 JUNCTION BLOCK XJ



Wiring Diagram CJ Models

1978 model wiring diagram key

NOMENCLATURE	LOCATION
Alternator/Regulator (Delco), V-8	A-2
Alternator/Regulator (Delco), 6 Cylinder	D-2
Backup Lamp, Left Rear	D-11
Backup Lamp, Right Rear	C-11
Backup Lamp Switch, Man. Trans.	E-2
Backup Lamp Switch, Auto. Trans.	D-9
Battery, 6 Cylinder	C-3
Battery, V-8	A-1
Bumper	B-1
Bumper Relay	C-7
Bumper Switch	C-8
Distributor, 6 Cylinder	D-3
Distributor, V-8	B-2
Electronic Ignition Pack, 6 Cylinder	C-2
Electronic Ignition Pack, V-8	A-2
Fuel Gauge	B-10
Fuel Sender	D-10
Fuel Sender Connector	E-10
Marker & Reflector, Left Rear	E-10
Marker & Reflector, Right Front	A-1
Marker & Reflector, Right Rear	A-11
Oil Pressure Gauge	A-10
Oil Pressure Gauge Light	A-10
Oil Pressure Sender, 6 Cylinder	D-4
Oil Pressure Sender, V-8	B-3
Park & Signal Lamp, Left Front	D-1
Park & Signal Lamp, Right Front	A-1
Resistance Wire-Alternator, 6 Cylinder	D-3
Resistance Wire-Alternator, 8 Cylinder	B-2
Resistance Wire-Coil, 6 Cylinder	D-3
Resistance Wire-Coil, 8 Cylinder	A-2
Splice "A"	C-6
Splice "B"	A-5
Splice "C"	B-7
Splice "D"	B-7
Splice "E"	C-7
Splice "F"	C-9
Splice "G"	A-3
Splice "H"	A-3
Splice "I"	C-2

Frame Harness Connector	E-9
Fuse Panel	C-5 & C-6
Fusible Link, Ignition Circuit, 6 Cylinder	C-3
Fusible Link, Ignition Circuit, V-8	A-3
Headlamp, Left	D-1
Headlamp, Right	B-1
Headlamp Ground, Left	D-1
Headlamp Ground, Right	B-1
Heater Blower Motor	A-5
Heater Blower Switch	A-6
Heater Resistor	A-6
Heater Control Lights	A-7 & A-8
High Beam Indicator	B-9
Horn	E-3
Horn Relay	C-7
Ignition Switch	C-8
Instrument Cluster	B-10
Instrument Cluster Lights	B-9
Instrument Panel Lights Ground	C-9
Kickdown and Quadra-Trac Switch Connector	E-2 & E-3
Light Switch	E-8
Light Switch Light	E-9
Marker & Reflector, Left Front	E-1
Splice "K"	A-2
Splice "L"	E-1
Splice "M"	E-1
Splice "N"	A-1
Splice "O"	A-1
Splice "P"	C-7
Splice "R"	D-3
Starter Solenoid	A-3 & C-3
Starting Motor	B-4 & D-4
Steering Column Connector	D-8
Stoplamp Switch	D-6
Tail, Stop & License Lamp, Left Rear	D-11
Tail & Stop Lamp, Right Rear	C-11
TCS System Connector	D-4
Temperature Gauge	B-10
Temperature Sender, 6 Cylinder	D-2
Temperature Sender, V-8	B-2
Turn Indicator & Hazard, Left	C-9
Turn Indicator & Hazard, Right	C-9
Voltmeter	A-9
Voltmeter Light	A-9
Windshield Wiper Motor	D-8