



Melex Golf Cart Wiring Diagram And Melex Golf Cart Battery Wiring Diagram By XPMissions

Melex golf cart wiring diagram and melex golf cart battery wiring diagram



Click to enlarge

ITEM	PART NUMBER	DESCRIPTION	QTY. USED
G01			
1	74564	Drive Motor	1
2	3979C22G01	Speed Control and Switch Ass'y., Complete	1
3	60013	Battery, 170 A.H.	4
5	06BLK0090DD	Lead Ass'y. — Battery Jumper	2
6	3979C24A01	Parallel Series Switch Ass'y.	1
7	70598	Battery Charger	1
8	80529	Horn Switch	1
9	16BLK0200BE	Lead Ass'y — Horn to Horn Switch	1
10	3979C21A01	Forward/Reverse Switch Ass'y.	1
11	60141	Horn	1
12	16BLK0370DE	Lead Ass'y. — Horn to Battery	1
G02			
1	74564	Drive Motor	1
2	3979C22G01	Speed Control and Switch Ass'y., Complete	1
3	60013	Battery, 170 A.H.	4
5	06BLK0090DD	Lead Ass'y. — Battery Jumper	2
6	3979C24A01	Parallel Series Switch Ass'y.	1
8	80529	Horn Switch	1
9	16BLK0200BE	Lead Ass'y — Horn to Horn Switch	1
10	3979C21A01	Forward/Reverse Switch Ass'y.	1
11	60141	Horn	1
12	16BLK0370DE	Lead Ass'y. — Horn to Battery	1
13	2907B64A01	Charger Receptacle Ass'y.	1
14	70608	Battery Charger	1