



Silverado Fuse Panel Wiring Diagram And Silverado Hear Light Wiring Diagram By XPMissions

Silverado fuse panel wiring diagram and silverado hear light wiring diagram

1999 Power Mirror Connectors

LH

RH



Connector Part Information		<ul style="list-style-type: none"> 12065659 10 Way M Metri-Pack Connector and Clip Assemblies (NAT) 	
Pin	Wire Color	Circuit No.	Function
A	ORN	2267	Fuse Output Heated Mirror Element
B	PNK	1691	Automatic Day/Night Mirror Return
C	YEL	1496	Power Mirror Motor Feed
D	LT GRN	89	Power Mirror Motor Feed Left Vertical
E	WHT	81	Power Mirror Motor Feed Left Horizontal
F	—	—	Not Used
G	GRY	1690	Automatic Day/Night Mirror Signal Return
H	BLK	1050	Ground
J	YEL	190	Folding Mirror Motor Feed Extend
K	LT BLU	191	Folding Mirror Motor Feed Retract

Pin	Wire Color	NO.	Function
A	ORN	2267	Fuse Output Heated Mirror Element
B	—	—	Not Used
C	YEL	1496	Power Mirror Motor Feed
D	PPL/WHT	889	Power Mirror Motor Feed Right Vertical
E	RED/WHT	881	Power Mirror Motor Feed Right Horizontal
F-G	—	—	Not Used
H	BLK	1050	Ground
J	YEL	190	Folding Mirror Motor Feed Extend
K	LT BLU	191	Folding Mirror Motor Feed Retract

Click to enlarge

Headlights/Daytime Running Lights (DRL) Schematics

